

# 1D Barcode Scanner

## User Manual

VZP1.0 1#

### System Setting



0B

Factory Defaults



0A

Show Version number



0B142

Open sound



014200

Close Sound

### Interface Setting



000602

Usb/Default



000600

Ps/2 /Keyboard mode



000601

RS232/Serial port mode



000603

VCOM/Virtual serial port

## Triggering mode Setting



013300

Default scan mode



013304

Automatic continuous scanning



013305

Automatic flicker



013302

Key delay

## Language Setting



0005000

American (default)



0005009

French



0005010

German



0005002

Brazil

## Suffix Setting



0212@\r

ADD- ENTER



0212@\r\n

ADD-ENTER-TAB



0211@[ETX]

ADD-ETX



0210@

Cancel the suffix