

Laser wireless scanner

Usage Guidelines

SW : V2.2.1W 20#

Default settings

If you accidentally scan other function settings during use, resulting in the scanning function not being able to be used normally, you can restore the default settings to the initial state by scanning them.



Default settings

Firmware software query

Displays the scanner factory software version.



Displays the scanner version number

Displays the receiver version number



Displays the receiver version number

Battery level inquiry



Displays the battery level

Working mode settings

Sound setting



Turn on the sound



Turn off the sound

Storage mode

The scanner stores the scanned data in memory.



Turn on storage mode



Turn off storage mode

Storage data settings

Query the total amount of data stored within the scanner.



Displays the total number of data

Upload all the data stored in the scanner.



Upload data

Upload a piece of data (the last data stored by the scanner).



Upload a piece of data

Erase all data stored by the scanner.



Clear data

2.4G pairing settings

A: After the scanner is turned on, it scans for "2.4G mode".



2.4G mode

B: Scan the "Pairing Code" scanner when the green light flashes rapidly, plug the receiver into the USB port of the device.



Pairing

C: After the scanner "beeps", it means that the pairing is successful.

Bluetooth pairing settings

A: Scan for "Bluetooth KBD mode" after the scanner is powered on.



Bluetooth KBD mode

B: Scan the "Pairing Code" scanner with a green light flashing rapidly.



Pairing

C: Connect Bluetooth in the custom software and search for the Scanner KBD.

D: The pairing is successful, and the blue light will be on.

Standby time settings

The scanner will automatically go to sleep when there is no operation within the set time range.



30 seconds



5 minutes



30 minutes



Not dormant



Shutdown

Keyboard language settings

Select the appropriate language according to the keyboard used in different countries

Please refer to the detailed manual for more settings



USA



France



Germany



Brazil



Spain

Terminator settings

The terminator is the last piece of data to be sent, and no additional data will be appended after it.



Enter



Enter and wrap the line



TAB



Cancel the end character